

DOKUMENTATION / DOCUMENTATION

ARTES Einspritzkühler Typ
Desuperheater type



dampfseitig / *steamside:*
wasserseitig / *waterside:*

Kunde / *Customer:*

Bestell-Nr. / *Order-No.:*

Projekt / *Project:*

Auftrags-Nr. / *Job-No.:*

Bau-Nr. / *Serial-No.:*

KKS-Nr. / *KKS-No.:*

TAG-Nr. / *TAG-No.:*

A MEMBER OF ARCA FLOW GROUP

Inhoudsopgave

Content

1. Bedrijfstechnische documentatie Manufacturing documentation

- Technische beschrijving inspuitskoeler
Operating and maintenance manual desuperheater
- Gegevensblad
Data sheet
- Maatbeeld
Dimension drawing
- Constructietekening
Assembly drawing
- Technische beschrijving actuator Documentation
actuator system

2. Kwaliteit documentatie *Quality documentation*

- Conformiteitsverklaring
Declaration of conformity
- Keuringsbewijs
Inspection certificate
- Batchrecordstelsel
Batch record
- Materiaalcertificaten
Material certificates

Betriebstechnische Dokumentation *Manufacturing Documentation*

ARTES Einspritzkühler Typ *Desuperheater type*



dampfseitig / *steamside:*
wasserseitig / *waterside:*

Kunde / *Customer:*

Bestell-Nr. / *Order-No.:*

Projekt / *Project:*

Auftrags-Nr. / *Job-No.:*


Bau-Nr. / *Serial-No.:*

KKS-Nr. / *KKS-No.:*

TAG-Nr. / *TAG-No.:*

A MEMBER OF ARCA FLOW GROUP

Desuperheater



A MEMBER OF THE ARCA FLOW GROUP

ARTES VALVE & SERVICE GmbH - Parkallee 7 - 16727 Velten - GERMANY -

Tel.: +49 3304-24724 10 - Fax: +49 3304-24724 99

www.artes-valve.com

Contents

| | | |
|-------|---|----|
| 1 | Identification..... | 4 |
| 1.1 | Valve Type plate | 4 |
| 2 | General..... | 5 |
| 2.1 | Use | 5 |
| 2.2 | Intended use | 5 |
| 2.3 | Warning symbols | 6 |
| 3 | Description..... | 7 |
| 3.1 | Design of the desuperheater..... | 7 |
| 3.1.1 | Seating Unit | 8 |
| 3.1.2 | Nozzle Unit..... | 8 |
| 3.2 | Mode of operation of the desuperheater..... | 8 |
| 3.3 | Mode of operation of the temperature control..... | 10 |
| 4 | Assembly instructions | 12 |
| 4.1 | General | 12 |
| 4.2 | Preparations for mounting..... | 12 |
| 4.2.1 | Mounting to connecting piece | 12 |
| 4.2.2 | Installation location | 13 |
| 4.2.3 | Installation in the line | 14 |
| 4.2.4 | Actuator | 14 |
| 4.2.5 | Insulation of the desuperheater | 15 |
| 5 | Pressure test in the plant..... | 16 |
| 6 | Startup | 17 |
| 6.1 | Startup steps..... | 17 |
| 6.2 | During operation | 17 |
| 6.3 | Dismounting from the pipe line | 18 |
| 6.4 | Disassembly of the desuperheater | 19 |
| 6.5 | Inspection | 19 |
| 6.6 | Assembly | 19 |
| 7 | Tests..... | 21 |
| 7.1 | Pressure test..... | 21 |
| 7.2 | Leak test | 21 |


| | | | |
|---------------------------------|--------------------------------|--|---------------|
| Created: | Checked/released: | Document: | Rev.: |
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

| | | |
|-----|-----------------------|----|
| 7.3 | Functional test | 22 |
| 8 | Spare parts list..... | 23 |

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

1 IDENTIFICATION

1.1 VALVE TYPE PLATE

| | | | | |
|--------------------|-----------------|-------|--|-------|
| Designation | 1) | | Opening Angle | 13) ° |
| Nominal Size | Steam | Water | Serial no. | 14) |
| | DN/NPS | 2) | | |
| Nominal Pressure | PN/class | 3) | Year of manufacture | 15) |
| | Design Pressure | 4) | | |
| Design Temperature | 5) | °C | KKS no. | 16) |
| Material | 6) | 11) | | |
| ○ 17) | Kvs value | 12) |  www.artes-valve.com GERMANY | |

| | | | |
|-----|---|-----|--|
| 1) | Designation | 9) | max. operating pressure - cooling water |
| 2) | Nominal Size - Steam Connection | 10) | at operating temperature - cooling water |
| 3) | Nominal Pressure Rating - Steam Connection | 11) | connection flange - material (Cooling Water Connection) |
| 4) | max. operating pressure - steam | 12) | flow coefficient (<i>K_{vs} value</i>) |
| 5) | at operating temperature - steam | 13) | opening angle |
| 6) | housing - material (Steam Connection) | 14) | serial number |
| 7) | Nominal Size - Cooling Water Connection | 15) | year of manufacture |
| 8) | Nominal Pressure rating - Cooling Water Connection | 16) | ID no. (<i>Tag no.</i>) |
| 17) | CE Mark (<i>if required</i>) | | |

| | | | |
|----------------|-------------------|--|---------|
| Created: | Checked/released: | Document: | Rev.: |
| on: 11.11.2019 | on: 23.11.2019 | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 |
| by: K/Schüler | by: Majewski | | 11/2019 |

2 GENERAL

2.1 USE

The desuperheater is used to control the temperature of steam and hot gases in power plants, chemical plants etc.

In this description, water is used as medium, for the sake of simplicity. The description analogously applies to other media.

The injected water is atomised to a micro-fine state by means of nozzles.

The integrated ball valve with the ball/seat ring system seals off the injection water.

To minimise wear, the ball is used as first throttle level, in special cases. This is noted in the valve data sheet, with the remark “*2-stage pressure reduction*”.

The fitting is installed directly in the respective steam or process line.

2.2 INTENDED USE

The desuperheater is exclusively intended for regulating the temperature of steam and hot gases by means of injection of cooling water. Any other or additional use has to be agreed upon contractually.

This technical description and the operating data listed on the valve type plate (see section 1.1 “VALVE TYPE PLATE”) have to be observed.

Adherence to local accident prevention and environmental protection regulations, as well as all customer specifications, is an integral part of intended use.

The safety information in the technical description has to be read prior to transporting, installing or repairing the desuperheater. The technical description has to be stored with care, so that its information is available at all times.

The technical description has to be accessible to the operating and service personnel at all times.

This technical description is intended for the service personnel of ARTES VALVE & SERVICE GmbH and the specialised personnel that have been trained by ARTES VALVE & SERVICE GmbH.

If the repair tasks are performed by untrained personnel, the guarantee automatically becomes void.

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

2.3 WARNING SYMBOLS

Safety instructions and warnings are aimed at preventing danger to the life and health of users or maintenance personnel, and at preventing material damage. They are highlighted by means of the signal terms defined here. Furthermore they are designated by warning symbols (pictographs) whenever they occur. The meanings of the implemented signal terms are as follows:



DANGER!

Immediate danger to health and life or danger of extensive material damage in the event of non-adherence to the instructions.



CAUTION!

Dangerous situation
Instructions on avoiding damage



NOTE!

Help, suggestions or hints
regarding a procedure.

| | | | |
|---|---|---|------------------------|
| Created: on: 11.11.2019 by: K/Schüler | Checked/released: on: 23.11.2019 by: Majewski | Document: 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | Rev.: 06 11/2019 |
|---|---|---|------------------------|

3 DESCRIPTION

3.1 DESIGN OF THE DESUPERHEATER




Fig. 3.1 Sectional view - Desuperheater Type 3

| | | | |
|-----|--------------------------|-----------|--------------------------------------|
| 1 | Housing | 13 | Base Ring |
| 1.1 | Bearing Bush | 19 | Disc |
| 1.2 | Lance Cap | 20 | Pointer |
| 1.3 | Lance | 25 | Mounting Bracket |
| 1.4 | Ring | 30 ... 35 | Gasket Set |
| 2 | Packing Housing | 38 & 39 | Fasteners - Packing Housing |
| 3 | Cooling Water Connection | 40 & 41 | Fasteners - Cooling Water Connection |
| 6 | Ball Stem | 42 & 43 | Fasteners - Stuffing Box Gland |
| 7 | Nozzle Stem | 45 & 46 | Fasteners - Mounting Bracket |
| 8 | Thrust Piece | 47 ... 49 | Fasteners - Pointer |
| 9 | Stuffing Box Gland | 51 | Cylinder Pin |
| 10 | Bearing Bush | 52 | Cylinder Pin |
| 11 | Bearing Bush | 53 | Circlip |

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

3.1.1 Seating Unit




Fig. 3.2 Sectional view - Seating unit

3.1.2 Nozzle Unit




Fig. 3.3 Sectional view - Nozzle unit

3.2 MODE OF OPERATION OF THE DESUPERHEATER

The temperature of steam and hot gases is controlled by regulating the cooling water injected into a steam or hot gas current.

With the desuperheater, it is possible to precisely control the injection quantity in accordance with the characteristic curve, by means of a special, individual nozzle control system that has been adapted to the operating conditions.

| | | | |
|---|---|---|------------------------|
| Created: on: 11.11.2019 by: K/Schüler | Checked/released: on: 23.11.2019 by: Majewski | Document: 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | Rev.: 06 11/2019 |
|---|---|---|------------------------|

The implementation of a nozzle system with integrated nozzle inserts enables constant, very fine atomisation of the cooling water in all load ranges. Water is supplied to the individual nozzles through boreholes in such a way that the characteristic curve of the valve has no steps.

The order in which the nozzles open has been determined by the design and construction. The nozzles located in the middle of the desuperheater are the first to inject cooling water.

The desuperheater has to be integrated into the pipe in such a way that the nozzle that opens first is located in the middle of the pipe. This ensures that the water is injected into the area with the highest flow speed, even when the flow rate is low. The distance between the first nozzle and the pipe wall is the largest. This largely prevents thermal shock at the pressurised steam line or insufficient performance in the case of low steam flow rates.

The ball valve that is integrated into the desuperheater blocks off the cooling water.

The tightness requirements for this blocking valve are specified in the contract. By default, the desuperheater complies with the requirements for control valves as set out in *EN 60534-4 - IV L 2* (the leakage flow, calculated for uniform conditions, is less than 0,01% of the K_{VS} value).

Other requirements have to be specially arranged.

The ball/seating-system is a pure metal seal and therefore can seal tightly for a long duration of time. When the differential pressure between the steam or hot gas and the cooling water is low, the entire differential pressure is applied at the nozzle systems, due to the very low loss of power within the desuperheater.

The differential pressure between the steam or hot gas and the cooling water should be at least 5 bar. If the differential pressure increases to values higher than 30 bar, increased wear at the nozzles should be expected.

The nozzle wear can be minimised by using multi-stage pressure reduction. Here the ball/seat ring system is used as first regulated throttle stage. The contour integrated into the ball and the control characteristics achieved by means of the nozzles form a unit.



To minimise the nozzle wear, it is possible to use nozzles made of *stellite*. Care must be taken that the quality of the injected water does not cause corrosion of the *stellite*. In power plants that apply the so-called “combi-mode”, it is not permissible to use *stellite*.

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

3.3 MODE OF OPERATION OF THE TEMPERATURE CONTROL


If no special agreements have been made, the control system of the desuperheater and actuator unit is not included in the scope of supply provided by ARTES VALVE & SERVICE GmbH.

The subsequent text describes a typical temperature control. This is only an example and is not binding for specific applications:

Three temperature sensors, located downstream of the desuperheater, measure the ACTUAL steam temperature and send the value to the control system. If the SETPOINT and ACTUAL temperature value deviate, the actuator of the desuperheater is activated.

Usually a 4 - 20 mA control signal is used. The fitting is closed at 4 mA.

The actuator sets the desuperheater to the required position, in accordance with the change in the control signal. The stem rotation causes the nozzles to be switched on and off and the appropriate



control characteristic is applied to control the injection quantity in accordance with the requirements of the valve's characteristic curve. This process continues until the SETPOINT and ACTUAL value match.

Normally feedforward control is achieved through input of valve settings for the steam flow control valves or "pre- and post-superheater" temperatures.

If no special agreements have been made, ARTES VALVE & SERVICE GmbH does not provide any warranty for the correctness of the control system (because it is not part of the scope of delivery).

Fig. 3.4 Schematic diagram - Mode of operation of the temperature control

Electric, pneumatic or hydraulic variable speed drives can be used as actuator for the desuperheater.

| | | | |
|---|---|---|------------------------|
| Created: on: 11.11.2019 by: K/Schüler | Checked/released: on: 23.11.2019 by: Majewski | Document: 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | Rev.: 06 11/2019 |
|---|---|---|------------------------|

The actuator and desuperheater are subjected to a functionality test prior to shipment.



We recommend that filtering strainers are installed in the cooling water line to prevent contamination of the desuperheater and to increase the maintenance intervals. **ARTES VALVE & SERVICE GmbH does not accept any liability for damage to the fitting caused by foreign objects.**

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

4 ASSEMBLY INSTRUCTIONS



Non-adherence to the following assembly instructions voids the warranty claims.

4.1 GENERAL



Desuperheater

- ⇒ The desuperheater may only be installed by the service personnel of ARTES VALVE & SERVICE GmbH or by trained specialists.
- ⇒ Care must be taken that no piping forces can act on the desuperheater.
- ⇒ The flange gaskets at the steam flange and at the cooling water connection have to be selected in accordance with the operating data. The manufacturer's specifications have to be observed.



Actuator

- ⇒ The instructions in the technical description of the actuator have to be observed. If it is not included as appendix, it has to be ordered.
- ⇒ The factory settings of the actuator may not be modified.
- ⇒ The max. permissible ambient temperature for the actuator may not be exceeded (observe the operating instructions of the actuator!).

4.2 PREPARATIONS FOR MOUNTING

4.2.1 *Mounting to connecting piece*



Prior to mounting the desuperheater, the following points have to be checked and documented, because the lance of the desuperheater must not touch other components:

| | | | |
|---------------------------------|--------------------------------|--|---------------|
| Created: | Checked/released: | Document: | Rev.: |
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

1. ACTUAL bore diameter of the connecting piece of the steam or hot gas line
2. ACTUAL hole circle diameter of the boreholes in the connecting piece of the steam or hot gas line
3. Distance from sealing surface of the connecting piece to the centre of the steam or hot gas line
4. Form and position of the connecting piece
5. Impermissible weld root penetration has to be eliminated.
6. The lance may not make contact with the steam line or thermoshock pipe on the opposite site of the steam connecting piece. Thermal expansion during operation has to be taken into account. If necessary, a borehole has to be made in the thermoshock pipe opposite.

4.2.2 Installation location

1. Choose an installation location where the desuperheater is always accessible.
2. If the fitting and the actuator together weigh more than 30 kg, a possibility to attach a chain hoist has to be provided for mounting the fitting in the steam line.
3. The actuator has to be easily accessible for adjustments.
4. There has to be a straight pipe of at least $5 \times d_{CL}$ upstream of the cooling water flange (d_{CL} - diameter of cooling water line).
5. There has to be a straight steam pipe of $5 \times d_{SL}$ upstream of the desuperheater (d_{SL} - diameter of steam line).



The specifications for the straight outflow section downstream of the fitting and the distance to the temperature sensors are listed in the data sheet of the valve. These minimum distances have to be observed.

| | | | |
|---------------------------------|--------------------------------|--|---------------|
| Created: | Checked/released: | Document: | Rev.: |
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

4.2.3 Installation in the line



The following points have to be taken into account when installing the desuperheater:

1. No forces and torques from the supply line of the injection medium may act on the desuperheater.
2. Care must be taken that no contaminations from the line can damage the desuperheater. The line section between the filtering screen and the desuperheater has to be checked. In new plants, it is recommended to design appropriately shaped weld seams.
3. When the fitting is mounted to the connecting piece, ensure that the axis of the desuperheater is aligned with the axis of the connecting piece. There has to be an even annular gap of at least *2.0 mm* between the connecting piece and the lance.
4. The screw connections at the steam and cooling water flange have to be tightened crosswise and evenly, with the torque required for the selected gasket and the respective application.



The water is injected through the nozzles, in the direction of flow of the steam!

4.2.4 Actuator



The desuperheater is supplied with a mounted actuator. If it is required to dismantle the fitting and actuator, the following instructions have to be observed. The technical description supplied by the manufacturer of the actuator also has to be observed.

1. The desuperheater has to be "*OPENED*" or "*CLOSED*" to a defined position by means of the actuator. In this position, the signal feedback of *4 - 20 mA* (normally) and the final position switch have been preset at the factory. **This final position has to be used for**

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

remounting the fitting and actuator! Mark the position (for example through a *coloured marking*).

2. During dismounting and mounting, take care that no forces and torques affect the spindle of the desuperheater. Otherwise damage to the ball of the ball stem (*pos. 6*), the seat ring (*pos. 5*) and the nozzle system (*pos. 15, 16, 17, 18 & 30*) cannot be excluded. During the mounting procedure, the screws have to be tightened crosswise at the required torque.



Never loosen the screw connection and turn the actuator on the desuperheater. The nozzle stem (*pos. 7*) will also be turned, with the result that the nozzles will not be activated correctly any more!

4.2.5 *Insulation of the desuperheater*



It is recommended not to enclose the steam flange and the cooling water flange in insulation. This makes it easier to detect leaks and no damage to the insulation, caused by leaks, occurs.

However, due to the high temperatures of the components, care must be taken that the components cannot be touched.

The insulation has to be fitted in such a way that the max. ambient temperatures for the actuator, as prescribed by the manufacturer, are not exceeded.

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

5 PRESSURE TEST IN THE PLANT



If a pressure test of the steam line with built-in desuperheater, this is 50% open. A pressure test of the cooling water side is possible. The test pressure must not be higher than the test pressure of the housing strength in the acceptance test certificate of ARTES VALVE & SERVICE GmbH. It should be noted that the desuperheater allows leakage.

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

6 STARTUP



The operating conditions stipulated in the purchasing contract have to be observed. Else the warranty becomes void.

The valve type plate of the desuperheater lists the design data for the steam and water side. These values may not be exceeded.

6.1 STARTUP STEPS

1. All screw connections have to be inspected while they are cold.
2. The actuator has to be run through its entire range while it is cold. If there is stiffness of movement, the packing has to be loosened.
The feedback signal and the final positions, as well as the intermediate positions (if applicable) have to be inspected and calibrated. The manufacturer's specifications and the operating manual of the actuator have to be observed.
3. The injection water line has to be vented at the highest point, else water hammer can damage the fitting. If the desuperheater itself is located at the highest point in the injection water line, the line can be vented into the steam line, via the fitting. To do so, the desuperheater has to be **completely open**.
4. When the operating temperature has been reached, all screw connections have to be inspected again and retightened if necessary.



Check that the packing has been tightened to the correct torque. At operating temperature it is possible that the packing blocks the spindle. This is entirely normal. If this occurs, loosen the packing until the spindle is not blocked any more. Here, as always, care must be taken to ensure tightness against leaks.

6.2 DURING OPERATION

During operation, the desuperheater has to be checked for leaks to the outside.

The frequency of the inspections depends on the plant requirements, however they should be performed at least every six months.

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

The revision intervals for the desuperheater primarily depend on the differential pressure between the water and the steam, and the water quality. These criteria are responsible for wear to the components. Normally servicing tasks are performed after 16,000 operating hours.

It is recommended that the desuperheater is always serviced after 24,000 operating hours.

Damage to the pressurised components is almost entirely impossible when proper operation is adhered to.



Only ARTES VALVE & SERVICE GmbH personnel or trained specialists may perform the servicing tasks, else the warranty becomes void.

6.3 DISMOUNTING FROM THE PIPE LINE

1. Switch off the section of the plant. The regulations applying to the plant have to be observed.
2. Obtain written confirmation that the plant is not pressurised (release).
3. Check the on-site temperature. The temperature of the components have to be lower than the temperature permitted by the relevant authorities.
4. Carefully loosen the flange on the water and steam side.
5. Remove from the steam line.



The actuator may not be used to lift the entire unit. If required, dismantle the actuator and fitting separately (also see section 4.2.4 "ACTUATOR")



The packing housing can be used to lift the desuperheater by means of a strap.

6. A Euro pallet can be used for transport purposes. Caution! Secure properly.

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

6.4 DISASSEMBLY OF THE DESUPERHEATER

All flange connections have to be marked prior to loosening them and have to be refit at the same positions later.

1. Dismount the actuator.
2. Dismount the cooling water connection.
3. Dismount the nozzles. Complete a nozzle protocol prior to disassembly (see Appendix)
4. Remove the unit formed by the mounting bracket (*pos. 25*), the packing housing (*pos. 2*) and the ball stem (*pos. 6*).
5. Dismantle into individual parts.
6. Clean all parts.

6.5 INSPECTION

All components have to be subjected to a visual inspection.

The degree of wear incurred on components that are subject to wear has to be determined.



If it cannot be guaranteed that the components will have high enough quality until the next service stop, the components have to be exchanged.

Use only original spare parts.

6.6 ASSEMBLY

Prior to assembly, the contact pattern of the seat ring (*pos. 5*) on the ball of the ball stem (*pos. 6*) has to be inspected. Regrind with diamond paste (*800 grit*) if required.

All bushings (*pos. 15*) have to be ground in on the nozzle stem (*pos. 7*) at the position where the assembly will take place later (*800 grit*).

For assembly, reverse the steps described at 6.4 "DISASSEMBLING THE DESUPERHEATER".

When assembling the nozzle system (*pos. 15, 16, 17, 18 & 30*), make sure that the entire surface of the bushings (*pos. 15*) make contact with the nozzle stem (*pos. 7*). Canting can cause grooves on the nozzle stem. This can lead to leaks.

When the nozzles are screwed in (*pos. 17*), the pure graphite ring (*pos. 30*) has to be pressed forward; subsequently the nozzle (*pos. 17*) has to be loosened again by a quarter turn. The torque of the ball

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

stem (*pos. 6*) and nozzle stem (*pos. 7*) have to be checked during assembly of each nozzle (*pos. 17*) (*stiffness*).

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

7 TESTS

7.1 PRESSURE TEST

The desuperheater has been subjected to a pressure test when it was new. The test pressure can be found in the documentation.

After the service tasks have been completed, the pressure test has to be repeated.



The steam flange of the housing is not subjected to a pressure test.
The pressure test for the steam flange is done in the plant.

7.2 LEAK TEST

It is necessary to differentiate between two leak tests:

- ⇒ Leak test for the ball/seat ring system
- ⇒ Leak test for the nozzles

The leak tightness of the fitting, in other words the ball/seat ring system, is done with water at a test pressure of *6 bar*.

Among themselves, the nozzles have to seal tightly, so that no undesirable drops of water resulting from untight nozzles can lead to thermoshock in the steam line during operation with partial load.

The nozzle tightness is checked with water, at a pressure of *6 bar*. To do so, the desuperheater is opened slowly. The nozzles then have to consecutively open and close in the prescribed order. If water escapes at the thread of the nozzle, the nozzle has to be tightened slightly. The ease of movement of the stem system (ball stem (*pos. 6*) & nozzle stem (*pos. 7*) may not be influenced. If necessary, regrind the bushing (*pos. 15*).

After the leak test has been completed, secure the nozzles against being turned to the wrong position. This is done by means of two punches.

| | | | |
|---------------------------------|--------------------------------|--|---------------|
| Created: | Checked/released: | Document: | Rev.: |
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

7.3 FUNCTIONAL TEST

The functionality of the desuperheater is tested together with the actuator. The torque, the feedback signal and the displacement switches are configured.

The technical description supplied by the manufacturer of the actuator has to be observed.

The technical description of the actuator can be found in the appendix.

| Created: | Checked/released: | Document: | Rev.: |
|---------------------------------|--------------------------------|--|---------------|
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |

8 SPARE PARTS LIST

The listed spare parts are recommended by the manufacturer.

| Pos. | Designation | Material |
|-------------|--------------------|---------------------------------|
| 5 | Seat ring | 1.4122 / 1.4923 |
| 6 | Ball stem | 1.4122 / 1.4923 |
| 7 | Nozzle stem | 1.4301 / 1.4923 |
| 8 | Pressure piece | 1.4541 / 1.4571 |
| 9 | Stuffing box gland | See parts list in documentation |
| 15 | Bush | 1.4122 |
| 16 | Ring | 1.4122 |
| 17 | Nozzle | 1.4122 / 1.4923 / Stellite |
| 18 | Nozzle insert | 1.4541 |
| | Gasket Set | |

| | | | |
|---------------------------------|--------------------------------|--|---------------|
| Created: | Checked/released: | Document: | Rev.: |
| on: 11.11.2019 by: K/Schüler | on: 23.11.2019 by: Majewski | 11-2019_Technical_Description_Desuperheater_3_Rev06.docx | 06 11/2019 |